

IMPORTANT!

READ ALL INSTRUCTIONS CAREFULLY

DO NOT DESTROY OR DISCARD ORIGINAL PACKING MATERIALS

It is imperative that you inspect your order as soon as your product has been received. CopperSmith cannot, under any circumstances, accept returns on products that have been installed. If a product arrives damaged, please save all original packing materials. Please photograph immediately and email the images to support@worldcoppersmith.com.

Disclaimer

Installation must be performed by a licensed professional only.

Installation must comply with all local building and safety codes.

Installation should not be scheduled until the product is received and inspected for damage or defect.

CopperSmith is not responsible for any installation delays or damages incurred as a result of installation.

CopperSmith is not responsible and does not supply any hardware or tools necessary for installation.

Do not apply painter's tape to any part of the range hood, as this may cause irreversible damage to the finish.

Vent Pipe Chart

Pro Series 395 CFM	7" round pipe
Pro Series 610 CFM	8" round pipe
Pro Series 1260 CFM	10" round pipe
Remote Blower 390 CFM	6" round pipe
Remote Blower 835 CFM	8" round pipe
Remote Blower 1260 CFM	10" round pipe

Island-Mount Range Hood Instructions

*** Please note that range hoods delivered with aluminum bracing bars may be installed with or without the bar intact. The bar may be removed to avoid installation obstruction and does not affect the overall structure of the installed hood ***

Step 1: Drill holes into the top flange of hood (one hole in each corner).

Step 2: Place U-channel across the floor joists or ceiling trusses where hood will be mounted with bolts installed to coordinate with pre-drilled holes.

Step 3: Lift and hold hood to the ceiling.

Step 4: Place U-channel inside the hood and underneath the flange, at location of pre-drilled holes.

Fasten hood to bolts with nuts and washers inside the hood. (Bolts should be secured through both sets of U-channels to properly fasten the hood to the ceiling).

Insert Fan Instructions

Step 1: Ensure exhaust pipe is in proper location to connect through the top opening of the hood

Step 2: Remove baffle filters from the insert fan. To remove, push the knobs on the baffle filters towards the back of the insert.

Step 3: A licensed electrician will then wire the insert fan. Wires should enter and connect directly from the ceiling.

Step 4: Lift insert into the hood opening.

Step 5: Ensure exhaust pipe is at the proper height inside the hood, then slide insert fan start collar into the existing exhaust pipe.

Step 6: Hold the insert fan inside the opening of the range hood at the apron, then drill through the left and right side of the insert fan, into the 4" vertical flange located inside the hood. Once pre-drilled holes are complete, utilize self-tapping sheet metal screws to fasten the liner in place.

*** If additional access to the exhaust pipe is needed, remove the motor inside of the insert fan to gain access. ***